

# Stonington Chandelier

CC1423 1.0

## VISUAL COMFORT & Co.

STUDIO COLLECTION

### GENERAL PRODUCT INFORMATION:

These fixtures are intended to be installed utilizing NEC compliant junction boxes.

This product is safety listed for damp locations.

Incandescent version may be dimmed with a standard incandescent dimmer. LED version may be dimmed with a LED dimmer. Consult lamp manufacturer for additional information.


This instruction shows a typical installation.

### CAUTION - RISK OF FIRE


This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.

Use minimum 90°C supply conductors.

**SAVE THESE INSTRUCTIONS!**



# Install the Fixture



- 1** Secure the mounting plate to the junction box.
- 2** Install the candle tubes by sliding them over the sockets.
- 3** Screw the lamps into the sockets. Refer to the label on the lamp socket for Max Wattage Information.
- 4** Feed the fixture wires through the fixture loop, then screw it onto the top of the fixture.
- 5** Determine the wanted height of the fixture and remove a portion of the chain from the bottom by opening a link with pliers.
- 6** Install a quick link to bottom end of the chain, then secure the quick link onto the fixture loop.
- 7** Install the other quick link onto the remaining end of the chain, then secure the quick link onto the canopy loop.
- 8** Weave the cord through the chain, canopy, and out of the junction box. Trim the cord leaving enough to make electrical connections.
- 9** Connect the fixture to a suitable ground in accordance to local electrical codes.
- 10** Connect the white fixture wire (square and/or rigid) to the neutral power line wire with a wire nut.
- 11** Connect the black fixture wire (round and/or smooth) to the hot power line wire with a wire nut.
- 12** Neatly place all the wires into the junction box, place the canopy onto the mounting plate, and secure it in place using the canopy screws.